

Ref: FAQ0072

Made By: AB 18/09/14

Version: 1.0

Title – Logger config for Email alarms

(Issue 2)

## Setting up Alarm emails from GPRS loggers via Radwin

Radwin can be configured to forward alarms to up to 20 different locations by SMS or GPRS (email).

We would always suggest that the logger is configured to send an alarm to Radwin, which can then process and archive the alarm, before passing it on to the required recipients.

Pros: A simple Radwin configuration change is all that is required if the recipient list changes. If the logger were to send directly to recipients the logger will need reprogramming each time a change is required. Alarm receiver will keep a log of the alarms. Less logger battery use to send 1 email as opposed to 8.

Cons: In the case of SMS will require 1 extra message than if the logger were to send directly to recipients only (assuming they don't want Radwin to receive an alarm). i.e. in this instance the logger could send 8 messages, 1 to each mobile only. In the preferred solution the logger will send 1 message to Radwin, and Radwin will send 8 messages to the recipients, so a total of 9 instead of 8. With email this is not a problem.

Configuration of the logger to send in email alarms to the Radwin host PC is as per your normal procedure. i.e Radwin Alarm programmer and receiver.

To configure Radwin to send alarm emails to other email addresses -

Open Radwin Set Up

Go to Options > Item Configuration select > Locations. This opens Zones and Locations Select the correct zone and location for the logger which is sending alarms into the host PC Identify the logger and double click on it

Scroll along the tabs to the Alarm/error exporting tab and select it. You should see the following-



## Ref: FAQ0072

Made By: AB 18/09/14

Version: 1.0

Title – Logger config for Email alarms

(Issue 2)

🚰 Locations	_ <b>_</b> ×	
	okup Tables 🏻 🙆 Data Manager	Type a question for help
ANDY : Andy's test zone	💼 🛛 🔀 🖬 🖬 🤧 🤧	
C:\Radwin\DATA\Andy 6		D B S pe a question for help
E Cones/Locations E ⊕7:		東東は小田 ▲・
🗉 🚸05 : Pt Vernon DMA	Location Configuration ANDY_B : Radwin All	
⊕ ∲ 0000 : ⊖ ∲ AMOY : Andy's test zone ↓ ↓ ↓ ↓ B : ⊕ ∲ D1 :	Katowa All     Autocall Memo Auto Database E     Katocall Vew     Autocall Autocall Memo Auto Database E     Autocall Autocall Memo Auto Database E	Is and Autocal errors may be automatically exported via export file, alarm/error may be exported to up to 20 different locations. Double
	Autocal Charles Auron Receiver Charles Autocal Charles	Create File Send SMS To Send Email To A state File Send SMS To A state File Send
		Logger Time: 21/05/2010 13:56:14 NUM
B	OK Cancel	
🏹 📰 💿 👻 🔯 5 Microsoft Offi 👻 [	Customer Services 👔 Sentinel & Pegasus 👹 Settin	gup Alarm 📓 Radcom View V4 🔛 Radcom Alarm R 🔣 Radcom Setup V4 < 🞯 🕫 🕼 🕸 🗘 13:56

Select and Double click on the first alarm – you should see this-

lert Type and Format	
Create Export File:00	_0F-2-100521-143144.txt
Send Alert To:	Browse,.
🗌 Send SMS Message to	0:
Send Email to:	

Click on Browse to find the person you want to email the alarm to.

Find the person if they are in the phone book – if not add then add the persons details by selecting 'Edit' and add email address if required.



Ref: FAQ0072

Version: 1.0

Title – Logger config for Email alarms

Made By: AB 18/09/14

(Issue 2)

	; telephone number, and email address, stored at honebook. Select OK to update the phonebook.	
hone Book Entry 01		
Name:	Andy Broadbent	
Telephone Number:	01633627876	
Email Address:	abroadbent@hwm-water.com	

## Then 'OK' Check the correct details in the list then 'OK' In the screen as below check the 'Send email to' box

ert Type and Format —		
Create Export File:	_00_0F-2-100521-143539.txt	
end Alert To:	Andy Broadbent	Browse
🗌 Send SMS Messa	ge to: 01633627876	
🔽 Send Email to: ab	oroadbent@hwm-water.com	
lessage Format:	ASCII	<ul> <li>Example</li> </ul>

Use the Example button in the above screen shot to check the format of the alarm is as required. Then 'OK'

In the same way set alarms and fill in the details for any other recipients.

Once complete Press the save button. And select 'OK' to update the logger zone & location with this information.

The configuration is now complete.

## **Document History:**

Edition	Date of Issue	Modification	Notes
1st	05/05/10	Release	
2nd	18/09/14	Update to New format	