

Quick Start Guide: COMLog 2 IS Installation (Using HWM IDT). (Automatic Meter Reading models).





Warning:

Always read this manual in conjunction with the Safety Supplement which contains important safety and operating information. Please read, understand and follow the instructions in the manuals. Additionally, carefully read and follow the information in the "Safety Warnings and Approvals Information" document.

1

MAN-157-0005-A November 2020

TABLE OF CONTENTS

Prepare	3
Choose Logger Model	4
Installation	5
Activate Logger / Wireless Communications	6
Checking and adjusting logger configuration.	6
Set Meter Reading of Flow Channel(s)	11
Add any additional Combos	13
Call settings and tests	13
Complete installation	14
	Prepare Choose Logger Model Installation Activate Logger / Wireless Communications Checking and adjusting logger configuration Set Meter Reading of Flow Channel(s) Add any additional Combos Call settings and tests Complete installation

Note(s):

- 1. Loggers will be set to call in with meter reading data and other messages to a server. This could be one of the HWM central servers or to your company's own server (with HWM logger communication software installed).
- Your logger may be pre-configured with a security setting requiring the use of the HWM DataGate or FCS OmniColl central servers; these are referred to as "secure loggers" and notes 5, 6 and 7 apply (see below).
 Without this security setting, the loggers are referred to as "insecure loggers" and notes 5, 6 and 7 do not apply (insecure loggers can be used without DataGate).
 Alternatively, notes 5, 6 and 7 can be optionally applied (insecure loggers can be optionally used with DataGate).
- 3. IDT will allow use without the app first logging in to the DataGate server (see link at the app login page) but will only work with insecure loggers.
- For additional information, refer to main product manual, MAN-157-0002 "User Guide: COMLog2-IS / ISLog - Installation and Setup".
- 5. Loggers must be pre-registered on DataGate.
- User must be pre-registered on DataGate.
 Contact your System Administrator (or your HWM Sales representative) to obtain your server URL, username, and password information, etc.
- 7. Assumes DMAs are pre-registered on DataGate.



.

The "Devices" page appears.



2 CHOOSE LOGGER MODEL

Several logger types are available. Examine the meter at the installation site and choose the correct logger model (and adaptor cables) for the job.



3 INSTALLATION

1. Un-pack logger

Dispose of packaging responsibly.





2. Install logger.

This product is only to be installed and connected by a **fully ATEX trained installer**.

Check on available space in the meter cabinet and decide where to position the logger, antenna, and cables. Ensure there is access to the magnetic sensor (see 4)

Securely mount the logger with suitable fixings; keyhole mounting holes are provided.

Note: The logger **should be installed upright** (pictured) to give best battery life.

If required, add anti-tamper seals between lid and base using holes provided.*

3. Connect antenna to logger

Place the antenna in a suitable location.

Connect antenna to the logger.

Ensure antenna cable has no sharp bends.

4. Connect logger to meter output(s).

Connect the logger Flow1 input to the meter output. Use a suitable adapter cable if required.

Alternatively, where a volume corrector is in place, Flow 2 can be used for corrected meter flow.

Use a suitable adapter cable if required.

If required, activate pulse repeat outputs of the logger, and connect to any downstream equipment (not shown).

Locate the cables so they cannot be damaged or cause a trip-hazard, and secure in position.

4 ACTIVATE LOGGER / WIRELESS COMMUNICATIONS

Logger must be activated during installation.

Hold a strong magnet in the position shown.

Wait 12s, then remove the magnet.

- If logger Bluetooth-compatible communications is in standby, it becomes active.
- Logger communications stays active for 120s, waiting for IDT to communicate.
- Communication with phone remains open for 600s after last use.



5 CHECKING AND ADJUSTING LOGGER CONFIGURATION.



Note: When using IDT app with DataGate login, insecure loggers may be hidden from lists. There is a menu option to view both secure and insecure loggers together.

2. Setup Logger ID and time-zone



3. Display existing Channel settings (summary)

The required logger settings will vary according to the meter and other equipment used at the site.

Channels

Tap the Channels icon.

(A "Combo" is a way of setting a combination of

conditions that, together, can generate an alarm).

A summary of number of channels and combos already configured is shown.

(The illustrations opposite show an example of a single flow channel with Tamper alarm set).

Flow channels appear as Logging channels. A tamper alarm uses a status input which appear as a Trigger channel.

÷	Channels	GLOBAL SETTINGS
Par	ameters	
	Sample Period:	Log Period:
	00:00:30	00:15:00
Log	ging Channels	
1 U	low1 Uni - Gas (ft³) nits/Pulse: 1 - Average	
Triç	ger Channels	
16	Status2_0 - Status (status) Multiplier: 1 - Time open	>> x1

÷



Object Object<	Sample Period	Log Period
Logging Channels	00:00:30	00:15:00
Flow1 Uni - Gas (ft ³)	Logging Channels	
1 Units/Pulse: 1 - Average	1 Flow1 Uni - Gas (ft³) Units/Pulse: 1 - Average	
	Frigger Channels	
Trigger Channels	Status2_0 - Status (status)	~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~

4	Check /	Edit	logger	Flow	Channel	1	settings
---	---------	------	--------	------	---------	---	----------

Tap the Flow channel line to show its details.

This screen is to set the volume measurement characteristics of the logger to match the meter's pulse outputs.

Note: These details can normally found within the data-sheet for the meter, but typically are found on the meter or pulse-head, as shown below.

1-PULSE =100dm.3

The meter unit above is metric, so the logger is required to be set up to use metric units (m³).

← Chai	nnel 1	i
BASIC	ADVANCED	TRIGGERS (0)
Input Sensor	Flow Uni 1.1	
Sensor Type	Gas	
Units/Pulse:	1	
Offset	0	
Recording Unit	ft³	
Logging Mode	Spot	

Check the "BASIC" tab channel settings match the meter, and if not adjust the settings.

e.g. Using the gas meter pulse characteristic shown above...

- The sensor type is set to Gas.
 This matches the meter. ✓
- The unit of measurement shown is set to ft^3 , which is an imperial measurement. imes
 - The channel requires adjusting to a metric measurement unit. Tap on "Recording Unit" and set to m³.
- The "Units / Pulse" field now requires editing. The volume represented by the meter-pulse needs to be scaled to the setting of the Recording Unit field.

"1 PULSE = 100dm³" corresponds to 0.1 m³ of gas per pulse.

The channel therefore requires adjustment of the "Units/Pulse" to be 0.1 to match.

• For a Flow reading, the channel must be set to "Spot" (the result is the pulse count since last measurement).

The edited screen is shown opposite. (Settings are correct for this example).

If any settings were changed, tap on the "ACCEPT" button.

ACCEPT	CANCEL
--------	--------

Input Sensor	Flow Uni 1.1
Sensor Type	Gas
Units/Pulse:	0.1
Offset	0
Recording Unit	m³
Logging Mode	Spot

5 Check / Edit logger Flow Channel 1 Pulse Sample rate and Pulse replication settings

Tap on the "Advanced" tab. Check the channel settings...

> The "Global pulse sample rate" should be set to "Low Power" for most meters, for best battery life. (Pulse width minimum 500ms, 50% duty cycle). "High Speed" must be set for meters with high pulse rates. (Pulse width maximum 10ms, 50% duty cycle). *Refer to the datasheet of the meter.*



• If required, the "Replicate Channel" control should be active, as pictured. (This setting ensures pulses from the Flow input are duplicated on the corresponding output, allowing down-stream equipment to use the meter pulses).

If any settings were changed, tap on the "ACCEPT" button.

6. Check / Edit Flow Channel 2 settings

If the logger is dual channel, repeat the checks and adjustments (steps 4 and 5) for the second meter measurement (e.g. from the volume corrector).

(Only required on dual-channel models. For single-channel models, the option is replaced by a Tamper Alarm option; see below).



7. Check / Edit logger Tamper Alarm settings

Some logger models can support a Tamper alarm to detect un-plugging of the logger from the meter.

If the logger is single channel, and the meter supports a tamper alarm, then confirm this is set up (see end of description). If not, follow the instructions below:

Tap on Combo:

No combos have been set up. Tap on the " + " line.



Combos Set trigger-action combinations on the device No: 0 Combos

Tap on "Tamper Alarm Combo" to set up the tamper alarm. (This activates IDT to make several changes to logger settings in order to produce a Tamper Alarm).

The tamper alarm settings are shown below (a) and (b):

(a)

A new channel is created measuring the open-circuit time of input Status2 (/ Flow2).

The channel input is tested every 2 seconds.

The channel is not logged.

The tamper input is not replicated to any output channel due to the "Replicate channel"

← Cha	nnel 16	i
BASIC	ADVANCED	COMBOS (1)
Input Sensor	Status2_0	
Sensor Type	Status	
Units/Pulse:	1	
Offset	0	
Recording Unit	status	
Logging Mode	Time open	

nnel 16	i
ADVANCED	COMBOS (1)
log and sample per	iods 🛛 📢
	00:00:02
	00:00:00
el	
	Inel 16

control being switched off (see diagram). (With this setting is not available for use by other equipment).

(b)

There is an alarm condition set up (via a "Combo" condition test).

The test checks the last 20 samples.

The OK condition (non-tamper) is for a closed-circuit to be present; the time of an open-circuit condition is to be "0".

The settings opposite create a trigger condition as soon as a single measurement shows an open-circuit condition exists.

The Action taken is to immediately report the alarm (to the server). It is to report it as a tamper condition.

(Functionality and settings in the server determine if the alarm is just recorded, or if it is actively forwarded to alert a user).

÷	Combo 1			
Trigge	r			匬
Channel:	16: Status2_0 (s	tat Sample va	lues	
Above 'A'		A= 0	_	
For 'C' of	last 'D' samples	C= 1	D= 20	
Hysteresis	5:	0.0		
	+ TRI	GGER		
Action	ř.			圓
Generate	an alarm			
Report ala	arm immediately	On activatin	g	
Send 'alar cleared' message	m 📢	Report as tamper alarm		

When the triggering condition no longer exists, the logger will also send an "alarm cleared" message. However, this will be sent when the unit next calls in to the server, not immediately.

Select a combo type

Custom combo

Tamper Alarm Combo

The channels summary shows the presence of the newly added channel and a combo being set to trigger in the new channel.

A summary of the tamper alarm combo is shown opposite and can be used to check if the combo has already been set. Channels No: 2 Combos: 1

If CH16 (Status2_0) is above 0 for 1 of the last 20 readings -Then- generate an alarm

← Channels	GLC SETT
Parameters	
Sample Period:	Log Period:
00:00:30	00:15:00
Logging Channels	
1 Flow1 Uni - Gas (m³)	
Units/Pulse: 0.1 - Average	
Trigger Channels	
Status2_0 - Status (status)	N

6 SET METER READING OF FLOW CHANNEL(S)

1. Set logger with current Meter Reading.

The logger tracks the volume of gas passing through the meter (from the pulses) and sends a meter reading into DataGate when it calls in with the flow measurements data.

Initially, the logger has not had the meter value set.

Tap on "Metering Settings".



Find the units the meter is displaying. For the meter in the example we are using, the dial clearly states "m³" (see diagram opposite).



The "Meter Factor" must next be determined and entered.

Meter factor = Unit of volume measurement used on the Meter for each digit

Unit of volume measurement used on the Flow channel

In our example: The flow channel was set up in m³ and the meter similarly measures in m³. The ratio would be 1 m³ / 1 m³; Set "Meter Factor" equal to "1".

Example 2: If the flow channel measured in ft³, whilst the meter measures in 100s of ft³, the ratio would be 100 ft³ / 1 ft³; Set "Meter Factor" equal to "100".



Read the main meter, noting its format. Enter the meter reading into the "Initial reading" field.

When entering the meter reading, include any leading zeros, the decimal point and any other displayed digits.



For the example shown, enter "020339 . 82".

Tap the back-arrow and the entered reading for Meter 1 is now shown. (This is not a live value).

You can confirm logger is set up correctly by doing the following:

After waiting for the meter to change by a few digits, note the meter reading and tap the "Meter Settings" control.

Confirm the "Current value" reading matches the meter reading (noted earlier).

If the reading is not correct, re-check:

The cables go to the correct meter.

The meter factor is correct.

The channel settings (units/pulse and recording unit) are correct.

... and then repeat the test.

Where two flow channels are used, the meter reading entry page will be as shown opposite.

Make the settings (as above) for each meter.

Add the initial reading and Meter Factor for the second meter.

Then tap the back-arrow.

A meter reading is now shown for both meters.



Metering Settings Meter 1: 020339.82 Meter 2: 000042.61

Confirm the readings of both "Current value" fields are operating as expected, using the method described earlier.

÷	Meteri	ng Settings	S
Flow Uni Initial rea	1.1 ding includ	ling all leading zeros	
02033	9.82		
Meter Fa	ctor		
x1			(c
	`		
000	1000	Metering Settings	
	<u>ر</u>	Weler 1. 020339.82	
	-		
÷	Meteri	ng Settings	S
← Flow Uni	Meterin	ng Settings	S
Flow Uni Initial real	Meterin	ng Settings ling all leading zeros	C
Flow Uni Initial rea 02033	Meterin 1.1 ading includ 9.82	ng Settings	C
Flow Uni Initial rea 02033 Meter Fa	Meterin 1.1 ading includ 9.82 ctor	ng Settings ling all leading zeros	C
Flow Uni Initial rea 02033 Meter Fa x1	Meterin 1.1 ading includ 9.82 ctor	ng Settings ding all leading zeros	S
Flow Uni Initial rea 02033 Meter Fa x1 Initial Set	Meterin 1.1 ading includ 9.82 ctor t Time: 22/	ng Settings ling all leading zeros 08/2019 15:06:47	G

1	
	Flow Uni 1.1 Initial reading including all leading zeros
	020339.82
	Meter Factor
	x1
	Initial Set Time: 22/08/2019 15:06:47
ſ	Current value: 020344.82
	Flow Uni 1.2
	Initial reading including all leading zeros
	000042.61
	Meter Factor
	x1
	Initial Set Time: 22/08/2019 16:01:18
ſ	Current value: 000043.61
- 1	

7 ADD ANY ADDITIONAL COMBOS

1. Add any required Combos.

If any additional alarms are required, they should be added by using a custom "Combo". (e.g. If flow rate exceeds rated flow of the meter).

8 CALL SETTINGS AND TESTS



3. Check CSQ level (If required). Network: vodafone UK 2G Signal Test Tap Modem: GE866-QUAD Get the signal quality from "Signal Test" the device's modem Firmware: 16.01.204 Close door of meter cabinet and check network CSQ level. History (tap to highlight) Summary of CSQ levels is shown below: 0-7 Poor. (The logger may be able to register with network but will not be able to send or receive data reliably). Acceptable. 8-14 (Depending upon the ambient conditions data transmission may be possible. It is important to select the correct antenna and install it in the most suitable location). 15+ Good. (Data transmission should be reliable). If required, adjust the antenna position or type to get best results. Check result with meter cabinet door open, for comparison. Move position Adjust height Change antenna type. (Where the meter cabinet is constructed of metal, it may be required to cut a hole and fit a button-type antenna). – Contact HWM for antenna options.

Repeat the call test when optimal antenna position is found.

9 COMPLETE INSTALLATION

1. Make a record of the logger deployment location (for office use).

2. Logger Deployment complete.

Leave site and go to the next site.

The logger communications will go into standby.





3. Logger makes measurements and logs data.

Logger takes measurements at regular sample intervals and saves datapoints at specified intervals.

4. Logger calls in with measurement data (when used with DataGate).

06:00, 09:30

(or other server)

DataGate

Logger contacts server at call-in time, and uploads measurement data. Logger can call server immediately if an alarm condition

is detected and the combo settings require it.

15

HWM-Water Ltd Ty Coch House Llantarnam Park Way Cwmbran NP44 3AW United Kingdom +44 (0)1633 489479 www.hwmglobal.com



©HWM-Water Limited. This document is the property of HWM-Water Ltd. and must not be copied or disclosed to a third party without the permission of the company. All images, text and designs are protected by international and UK copywrite law and remain the property of HWM-Water. It is against the law to copy or use any of the content from the HWM website or literature without the written consent of HWM-Water. HWM-Water Ltd reserve the right to vary the specification.

MAN-157-0005-A November 2020.