	Ref: FAQ0118	Version: 1.0
	Title – Digicall firmware level check	
	Made By: AB 15/059/15	(Issue 2)

How to check the level of Digicall PC software and whether it is the latest available.

Open the software and at this screen below click on the 'Help' tab.

This will reveal the level of the software you are using.

Note – the latest version can be found on the www.hwm-water.com website where both software and installation instructions are listed.

Document History:

Edition	Date of Issue	Modification	Notes
1st	30/07/12	Release	
2nd	15/09/15	Format update	