

Ref: FAQ0422

Made By: AB 21/11/17

Version: 1.0

Title –Intelligens WW Breather Maint'ce

(Issue 1)

Intelligens Waste Water breather maintenance

It is essential to carry out routine maintenance on the equipment Breathers to ensure continued accurate data.

The crystals should be swapped as soon as colour change is seen in order to protect the breather tube and pressure sensor. Unfortunately this can be required every week at some sites.

The Gore-Tex filter system should be swapped out and the used ones brought back for cleaning and replacement of the crystals as a workshop procedure. What works well is using a fish tank air pump. Place the breather tube with crystals on a heated surface and blow air through the system until crystals turn yellow. This proves the crystals and Gore-Tex filter system are working correctly, fully operational and not blocked.



Document History:

Edition	Date of Issue	Modification	Notes
1st	21/11/17	Release	

This document is the property of HWM-Water Ltd. and must not be copied or disclosed to a third party without the permission of the company. Copyright reserved. Halma Water Management, Ty Coch House, Llantarnam Park Way, Cwmbran, Gwent. NP44 3AW. www.hwm-water.com; Tel: +44 (0) 1633 489479; Fax: +44 (0) 1633 877857