



Ref: FAQ0357

Version: 1.0

Title – Microcall + PC Software

Made By: AB 28/01/15


(Issue 1)

## How to transfer data from MicroCALL+ to your PC and Analyse it

You will need to download two pieces of software from our website.

1. The utility you need is the “MCP/ACD File Transfer Utility”. This allows transfer of correlation results files to the PC.

(You can download this utility by going to the HWM website [www.hwm-water.com](http://www.hwm-water.com) going to the ‘Support’ tab, ‘Software and firmware updates’ and clicking the link highlighted below. If you are not already registered on the website you will be asked for your details and we will give you access by return email.)



2. If you want to examine the results on the PC you can use the application “DigiCALL”.

DigiCALL can be downloaded by following the link highlighted below.




Ref: FAQ0357

Version: 1.0

Title – Microcall + PC Software

Made By: AB 28/01/15

(Issue 1)



Operation of the software can be found starting on Page 14 of the DigiCALL+ manual which you can download from the same website.

#### Document History:

Edition	Date of Issue	Modification	Notes
1st	28/01/15	Release	