

Ref: FAQ024

Made By: AB\_06/02/14

Version: 1.0

Title – MicroCORR + radio testing

(Issue 1)

## Question – How to test the radios in a MicroCORR +

This can be carried out using the "Radio Test" and "Signal Strength Meter"

From the Main Menu

Select Option '6' for Information Then select option '4' for Diagnostics, or Select option '5' for Signal Strength Meter And then select Option '2' for Radio Test

The test should pass with a percentage rate of 80% + as per the screen shots below.

		Perfect ter %	Count	OK ter %	Coun	Failed ter %	
1	F.	100.00%	5	100.00%	p	0.00%	
1	به ۳»	100.00%	4	100.00%	p	0.00%	
V							
1	T Putst	ation not detecte	d. Is it with	nin radio range an	nd switched	t on?	
Y							
				ОК			



Ref: FAQ024

Version: 1.0

## Title – MicroCORR + radio testing

Made By: AB\_06/02/14

(Issue 1)



					P
0	PRBS Passed PRBS Failed ZERO Passed ZERO Failed	-> R: -> R:	9 B:	0 Y:	

## **Document History:**

Edition	Date of Issue	Modification	Notes
1st	06/02/14	Release	