



Ref: FAQ0039

Version: 1.0

Title – When are Meter Readings transmitted?

Made By: KE190514\_(Issue 1)

### Question –

**When is the meter reading from a logger transmitted, and is it possible for the meter reading to change between transmissions?**

Generally the meter read is sent in the first call in after midnight.  
The meter read reported is the reading at the time of call in.

However, meter reads can appear more frequently for example in the first call after a call failure or if a remote configuration has taken place.

Example: A logger is configured to call in a 08:00, 14:00 and 20:00

If the logger has no problem calling in, then the meter reading will be transmitted at 8:00, and the same meter reading will be transmitted at 14:00 and 20:00

08:00 – 234567

14:00 – 234567

20:00 - 234567

However, if the logger does have a problem calling in, or the logger is re-configured during the day, you may see the following;

08:00 – 234567

14:00 – 234567

20:00 – 234789

### Document History:

Edition	Date of Issue	Modification	Notes
1st	19/05/14		1 <sup>st</sup> release