



Ref: FAQ0200

Version: 1.0

Title -LX loses comms with ext batt pack

Made By: AB 17/09/15

(Issue 2)

LX loses IR comms ability when external battery pack is connected

If you plug an External battery box into an LX GPRS logger then the infrared port is shut off for a few minutes after doing it – This is caused by the logger noticing it has external power so that it registers itself onto the network during which time it shuts down local comms (infrared connection).

Note - if the LX doesn't have an external batt box it will ignore fast call in times and default to only 2 call ins per day at 6am and 6pm

Document History:

Edition	Date of Issue	Modification	Notes
1st	14/01/13	Release	
2nd	17/09/15	Format update	