

**Ref: FAQ0339****Version: 1.0****Title –Multilog & LX GPRS – SMS backup****Made By: AB 17/09/15****(Issue 2)**

Multilog and LX GPRS loggers – how SMS back up call in works

SMS 'back up' call in works as follows.

Suppose the logger is set to send in by GPRS three times a day 8.00; 13.00; and 18.00. If at 8.00 it cannot get a signal it will try at 13.00. If it gets a signal at 13.00 it will send both sets of data. If it can't get a signal it will try again at 18.00. If it gets a signal it will send three parts of data. If it can't get a signal it will wait until 24.00 and send a single SMS. If it can't get an SMS signal it will try every 15 mins until 8.00 when it will try GPRS again. So it will only send one SMS per 24 hour period.

It is one SMS per channel or 2 per 3 channel as it is compressed the same as normal Multilog.

Document History:

Edition	Date of Issue	Modification	Notes
1st		Release	
2nd	17/09/15	Format update	