



Ref: FAQ0208

Version: 1.0

Title – Permalog+ operating modes

Made By: AB 18/09/15

(Issue 2)

## Permalog + explanation of different operating modes

**Patrol Mode** (which is same as Default settings) is when the P+ transmits its leak data every 2 seconds and listens for command every 40 seconds; patrols last for 8 hours per day.

**Fixed Network Mode** is where the P+ transmits its leak data every 8 seconds and listens for command every 16 seconds; patrols last 24 hours per day.

**Lift & Shift** has no patrol window (no radio settings) – you pick up the Permalog, swipe it with a magnet to switch it on - It transmits the data to the Patroller for approx 60 seconds and then the radio goes back into sleep mode automatically ( it is of course still recording data – only the radio has gone to sleep)

### How can you check if a particular Permalog is in Fixed Network or Patrol Mode?

You cannot check this..... but you can get a good indication by looking at the individual Permalogs settings in the Patrol Window Screen –

- If the boxes are checked 8am to 4 pm - it is likely to be in patrol Mode
- If all the boxes are checked 12am to 12pm – it is likely to be in Fixed Network Mode
- If none of the boxes is checked is set it is likely to be in lift & shift mode

### Document History:

Edition	Date of Issue	Modification	Notes
1st	21/01/13	Release	
2nd	17/09/15	Format update	