



Ref: FAQ0058

Version: 1.0

Title – Data logger pressure connection

Made By: AB 05/09/14

(Issue 1)

Question –What is the assembly of pressure fittings between the logger and the water main

RAPC03 Coiled hose



Connect logger to quick fit connector on hose

RAPC02 ¼ BSP
Quick release
fitting

COU5005



Connect COU5005 ½ BSP
taper thread to ½ BSP
threaded hole in water main

Connect male quick fit to RAPC03 quick fit
connector which has ¼ BSP thread

Connect RAP C02 to
COU5005 (use sealing
washer – not shown)

Document History:

Edition	Date of Issue	Modification	Notes
First	05/09/14	Release	