How to configure rate of change alarms

Rate of change Alarms can be configured in Radcom data loggers which enable situations where a parameter rapidly increases or decreases to generate an alarm condition.

The rate of change alarm operates on the unit of the particular channel configured – so if channel is measuring flow in metres/ sec then rate of change will be in metres/sec as well . If the configured rate of change is exceeded the alarm will be triggered.

Document History:

Edition	Date of Issue	Modification	Notes
1st	02/01/13	Release	
2nd	17/09/15	Format update	