



Ref: FAQ0151

Version: 1.0


Title –SonicSens head install dimensions

Made By: AB 15/09/15

(Issue 2)

SonicSens head installation dimensions

The basic installation dimensions for the Standard SonicSens head is as below -



Optional extension arms are available which extend the max distance from 370mm to 500mm

Document History:

Edition	Date of Issue	Modification	Notes
1st	11/09/12	Release	
2nd	15/09/15	Extension arms added	