



Ref: FAQ 0006A

Version: 1.0

Title – Datagate FTP settings for Wi5 GPRS

Made By: AB\_050215

(Issue 1)

## Question – how can I change the FTP details in a Wi5 GPRS to send its data to new FTP site

In the example below the default HWM Datagate details are used for illustration.  
Firstly send a STATUS text message to the Wi5 so you know the current settings and the format  
The response should show the FTP details as *loggers:radcom@wi5.hwmonline.com*

The FTP settings for a Wi5 GPRS are;

FTP Server Address : *wi5.hwmonline.com*

Username: *loggers*

Password: *radcom*

Path: *wi5*

If you need to set these via a TXT message, you can use the following commands;

NB: This sets the Primary FTP destination to Datagate

SET FTP ADDRESS *wi5.hwmonline.com*

SET FTP USER *loggers*

SET FTP PASS *radcom*

SET FTP PATH *wi5*

If you wish to set Datagate as the Secondary FTP destination, then you would program as follows;

SET FTP ADDRESS2 *wi5.hwmonline.com*

SET FTP USER2 *loggers*

SET FTP PASS2 *radcom*

SET FTP PATH2 *wi5*

### Document History:

Edition	Date of Issue	Modification	Notes
1st	06/11/13		
2nd	20/02/15	Update FTP address to latest	