



Ref: FAQ 0006

Version: 2.0

Title – Datagate FTP settings for Wi5 GPRS

Made By: AB_200215

(Issue 2)

Question – What are the correct FTP settings I need to enter into a Wi5 GPRS to send its data to Datagate

The Datagate FTP settings for a Wi5 GPRS are;

FTP Server Address : wi5.hwmonline.com

Username: loggers

Password: radcom

Path: wi5

If you need to set these via a TXT message, you can use the following commands;

NB: This sets the Primary FTP destination to Datagate

SET FTP ADDRESS wi5.hwmonline.com

SET FTP USER loggers

SET FTP PASS radcom

SET FTP PATH wi5

If you wish to set Datagate as the Secondary FTP destination, then you would program as follows;

SET FTP ADDRESS2 wi5.hwmonline.com

SET FTP USER2 loggers

SET FTP PASS2 radcom

SET FTP PATH2 wi5

Document History:

Edition	Date of Issue	Modification	Notes
1st	06/11/13		
2nd	20/02/15	Update FTP address to latest	