

**Ref: FAQ0070****Version: 1.0****Title – GPRS Wi5 Reset****Made By: AB 15/12/14****(Issue 1)**

How to reset a GPRS Wi5 Data Concentrator

The internal Battery acts as a 'boost' to the power supply when the Wi5 tries to connect to the GSM network.

If the battery is very flat, you should leave the WI5 plugged in on Mains power with the battery connected for an hour or so to let the battery charge, then do a full reset as follows :-

- 1.) Remove USB Cable (if connected)
- 2.) Remove Mains Power
- 3.) Remove Battery
- 4.) Wait 3min
- 5.) Reconnect Mains, Battery, USB in that order

Wait 3min and providing the GSM signal strength in the area is strong enough, it should connect.

Document History:

Edition	Date of Issue	Modification	Notes
1st	15/12/14	Release	