



Ref: FAQ0176

Version: 1.0

Title – MicroCORR 6 Calibration message

Made By: AB 17/09/15

(Issue 2)

## MicroCORR 6 - how to override the calibration requirement

On MicroCORR 6 there is a sequence to go through to eliminate the Calibration message as follows:-

1. Power on the unit.
2. Press 'Menu' button
3. Select 'Print' then '02' then 'Enter'
4. Select 1 (Print list) then 'Set' then 'Enter' - make sure **OPTION 1 (print)** and **SET** are pressed simultaneously and then enter.
5. At the Calibration screen you will see a Date of calibration entry. If you enter the date with a year entry of 99 (corresponding to 2099) you should not see the message again (until 2099!)

### Document History:

Edition	Date of Issue	Modification	Notes
1st		Release	
2nd	17/09/15	Format update	