



Ref: FAQ0177

Version: 1.0

Title – MicroCORR 6 – reset procedure

Made By: AB 17/09/15

(Issue 2)

MicroCORR 6 – Reset procedure

Switch on Machine

Press 'MENU'

Select option '09 SELF TEST' and select 'ENTER'

You are looking to clear the memory

Press '1,2,3,4 for RAM CLEAR'

To clear memory Press '1' and 'ENTER'

This re-initialises the Machine.

It will now go back to the power up screen.

Switch the Machine 'off' and back 'on' again.

Document History:



Ref: FAQ0177

Version: 1.0

Title – MicroCORR 6 – reset procedure

Made By: AB 17/09/15

(Issue 2)

Edition	Date of Issue	Modification	Notes
1st		Release	
2nd	17/09/15	Format update	