

PATROLLER

Patroller II PDA Software Installation Guide

Patroller II PDA Software Installation Guide

MAN-096-0003

Issue A

Date 2/08/07

Written by AS

Palmer Environmental Ltd
Ty Coch House
Llantarnam Park Way
Cwmbran
NP44 3AW
United Kingdom

Tel: +44 (0) 1633 489479

Fax: +44 (0) 1633 877857

Email: info@palmer.co.uk

Web: www.palmer.co.uk

Patroller II PDA Software Installation Guide

1. Install Microsoft ActiveSync on PC if not already installed.
2. Connect PDA via USB cable to PC.
3. Wait for PDA to beep.
4. Copy Files from CD to Mobile Device Drive using Window explorer.

Name ▲	Size	Type	Date Modified	Attribu...
BlueTools.arm.CAB	684 KB	WinZip File	11/09/2006 12:32	A
NETCFv2.wm.armv4i.cab	2,185 KB	WinZip File	13/06/2006 18:32	A
Patroller.CAB	675 KB	WinZip File	22/06/2007 08:09	A
sqlce30.wce5.armv4i.CAB	1,549 KB	WinZip File	03/09/2005 07:40	A

5. Disconnect the PDA from PC.
6. On the PDA open file explorer.
7. Click on NETCFv2.wm.armv4i.cab and follow instructions. You will be prompted to restart PDA.
8. Once restarted, open file explorer.
9. Click on sqlce30.wce5.armv4i.cab and press OK when finished.
10. Click on BlueTools.arm.CAB and press OK when finished.
11. Click on Patroller2.cab and press OK when finished.
12. The Patroller II software has now been installed and ready to use.

PLEASE NOTE THAT FILES MUST BE ACTIVATED IN THE ABOVE ORDER

Contact

Palmer Environmental Ltd

Ty Coch House

Llantarnam Park Way

Cwmbran

Gwent

NP44 3AW

United Kingdom

Tel: +44 (0) 1633 489479

Fax: +44 (0) 1633 877857

General Enquires: information@palmer.co.uk

Technical support: support@palmer.co.uk

Web: <http://www.palmer.co.uk>

Note

Palmer Environmental reserves the right to change products, services or specifications without notice.

Patents

The Permalog® system is patented in the United Kingdom:

GB2335041, GB2361062, GB2361319, GB2361540 & GB2361541

Patents pending in Europe, United States and Japan.

Permalog® is a Registered Trademark of Palmer Environmental.