



**Ref: FAQ0007**

**Version: 1.0**

**Title –SoundSens – error messages**

**Made By: AB 23/09/15**

**(Issue 2)**

## **SoundSens – an explanation of error messages**

‘Linear drift’ means the pod clocks have drifted apart too much, it is recommended that loggers are downloaded within 24 hours of syncing with the suitcase to prevent this.

‘Low logger noise’ means the recorded noise level is too low, which could indicate either a faulty pod or a badly installed logger.

### **Document History:**

<b>Edition</b>	<b>Date of Issue</b>	<b>Modification</b>	<b>Notes</b>
1st	20/11/13	Release	
2nd	23/09/15	Format update	