

PATROLLER

Patroller II Quick Guide

Patroller II Quick Guide

MAN-096-0004

Issue A

Date 27/07/07

Written by SMK

Palmer Environmental Ltd
Ty Coch House
Llantarnam Park Way
Cwmbran
NP44 3AW
United Kingdom

Tel: +44 (0) 1633 489479

Fax: +44 (0) 1633 877857

Email: info@palmer.co.uk

Web: www.palmer.co.uk



Patroller II Quick Guide

Step 1) Pair the Interface Unit to PDA

Turn the Patroller II Interface unit on by pressing the on/of button on the front of the unit, the LED will light and initialise Bluetooth communications.

Create a new partnership on the PDA's Bluetooth configuration screen. Select the Patroller Interface unit (Patroller II xx.yy—where xx.yy are the last four digits of the Bluetooth identity). If asked, use a passkey of 0000 (four zeros) and ensure "Serial Port" is selected.

Step 2) Setting the default device in the Patroller II Software


Launch the Patroller II software . From the main screen, click the "PDA Setup" icon . In the new window, using the dropdown box, select the paired Interface unit. Click "Save" then close the window by pressing "X".

Step 3) Creating a new DMA (optional)

From the main screen, click the "DMA" icon . Click "New" and enter the information in the new window. Click "Save" to save the new DMA in the database.


Create as many DMA's as required.

Step 4) Deploying Loggers

From the main screen click the "Deploy" icon . Click "New". Enter the loggers information on screen and (if created) add the logger to a DMA.

Add as many loggers as required.

Step 5) Starting a Patrol

With the DMA and loggers created in the database carry out a patrol by clicking the "Patrol" icon from the main screen .

As you drive/walk around the DMA, loggers within range will be displayed on screen along with their status. Information given is "Serial No. - Leak Status - Level - Spread and Time"

Leak Status is displayed as:

L = Leak Detected

N = No Leak

Contact

Palmer Environmental Ltd

Ty Coch House

Llantarnam Park Way

Cwmbran

Gwent

NP44 3AW

United Kingdom

Tel: +44 (0) 1633 489479

Fax: +44 (0) 1633 877857

General Enquires: information@palmer.co.uk

Technical support: support@palmer.co.uk

Web: <http://www.palmer.co.uk>

Note

Palmer Environmental reserves the right to change products, services or specifications without notice.

Patents

The Permalog® system is patented in the United Kingdom:

GB2335041, GB2361062, GB2361319, GB2361540 & GB2361541

Patents pending in Europe, United States and Japan.

Permalog® is a Registered Trademark of Palmer Environmental.