



Ref: FAQ0198

Version: 1.0

Title-Radcom loggers –LX mount bracket

Made By: AB 17/09/15

(Issue 2)

Radcom loggers – how to use the Multilog LX mounting bracket

Screw the bracket to the wall of the chamber

Hang the battery box on the return

Attach the Antenna to the flat surface of the bracket using its magnet

Either screw or cable tie the logger to the holes in the front face of the bracket



Document History:

Edition	Date of Issue	Modification	Notes
1st	14/03/13	Release	
2nd	17/09/15	Format update	