

**Ref: FAQ0202****Version: 1.0****Title – Permalog+ how to discover****Made By: AB 17/09/15****(Issue 2)**

## How to 'discover' Permalog + loggers with PDA/Patroller

For the loggers to be 'discoverable' they must be:-

- Switched on
- Within radio range of the patroller
- In the patrol window (if the logger is not in the patrol window time, swipe it with the magnet of another logger and it will transmit for two minutes)

Please ensure that not too many loggers are 'discoverable' at the same time. When there are many loggers in close proximity to the Patroller the transmissions can overlap and it may not be possible to discover all loggers. Do not have the Patroller in close proximity to the loggers. You need a gap of more than 5m or alternatively try removing the antenna from the logger.

It is suggested that you take one logger and the Patroller, make sure no other loggers are in the vicinity. Swipe the logger with a magnet and then after a couple of seconds try to 'Discover'. Once you have completed this, aside the logger out of the vicinity and repeat the process with another logger.

### Document History:

Edition	Date of Issue	Modification	Notes
1st	21/01/13	Release	
2nd	17/09/15	Format update	