

**Ref: FAQ025****Version: 1.0****Title – wiring HRI Mei to Radcom Flow****Made By: AB_07/02/14****(Issue 1)**

Question – how to connect a Sensus HR1 Mei Sensor to a Radcom logger flow channel

The HRI Mei B1 or B4 will work if wired to a 4 pin amphenol connector because neither of these variants require power from the logger. Other variants of HRI Mei are not suitable as they will rapidly deplete the logger battery pack

Wiring for Sensus HR1 Mei

HR1 Mei B4	Description	Logger 4 pin amphenol
No connection		A
White	Channel 1 pulses	B
Grey	Ground	C
Yellow	Direction flag	D

Document History:

Edition	Date of Issue	Modification	Notes
1st	07/02/14	Release in FAQ format	